

Instructional Technology

- For Dental School rooms 103, 105, and 124

Instructional Training Equipment


The equipment in these rooms consist of a PC Computer, Monitor, Data Projector, and Document Imager.

The Instructional Training Equipment in all of these rooms are accessed and controlled by a touch screen.

Entering the Password

WELCOME TO
THE UNIVERSITY OF LOUISVILLE
DENTAL SCHOOL
PRESS HERE TO BEGIN

PASSWORD



1:00

11/11

- Press the word **PASSWORD**.


Entering the Password

WELCOME TO


1	2	3
4	5	6
7	8	9
Clear	0	Enter


- Type the password provided to you by IT/IS Media.
- Press **Enter**.


Turning on the System


 **LIGHTS**


ALL
ON





 **SCREEN**





MAIN MEU

MUST POWER PROJECTOR FIRST...

VHS
VCR

DVD

Visualizer

Laptop
Computer

Auxiliary
Video

Control
Room

Slides

Workstation
Computer

SYSTEM POWER

ON

OFF

1:00

11/11

PGM
VOL


UP

DN


Welcome


- Press the **On** button


Turning on the System


 **LIGHTS**


ALL ON





 **SCREEN**





VIDEO PROJECTOR POWER

DO YOU WISH TO USE THE VIDEO PROJECTOR?

YES

NO


VIDEO MUTE


ON **OFF**

1:00

11/11

PGM VOL

 **UP**

 **DN**

Welcome

- Press the **YES** button

1:00

11/11

SYSTEM CONFIGURING



PLEASE WAIT...



LIGHTS

ALL

ON



SCREEN



MAIN MEU

PLEASE SELECT THE DEVISE YOU WISH TO USE...

VHS
VCR

DVD

Visualizer

Laptop
Computer

Auxiliary
Video

Control
Room

Slides

Workstation
Computer

SYSTEM POWER


ON

OFF

1:00


11/11

PGM
VOL





Welcome


To Activate Laptop Controls


 **LIGHTS**


ALL
ON





 **SCREEN**





MAIN MEU

PLEASE SELECT THE DEVISE YOU WISH TO USE...

VHS
VCR

DVD

Visualizer

**Laptop
Computer**

Auxiliary
Video

Control
Room

Slides

Workstation
Computer


SYSTEM POWER


ON OFF

1:00

11/11

PGM
VOL

 UP

 DN

Welcome

Press the **Laptop Computer** button

Laptop Screen


LAPTOP COMPUTER

1:00

11/11

PGM

VOL



Device Activated

VIDEO MUTE

ON

OFF



Quit to
Main Menu





LIGHTS

ALL

ON



SCREEN



To Exit the Laptop Screen



LAPTOP COMPUTER

1:00

11/11

PGM

VOL



Device Activated

VIDEO MUTE

ON

OFF



Quit to
Main Menu




LIGHTS

ALL

ON



SCREEN



Press the **Quit to Main Menu** button

To Use the VCR

Main Menu

1:00

11/11

PLEASE SELECT THE DEVISE YOU WISH TO USE...

VHS
VCR

DVD

Visualizer

Laptop
Computer

Auxiliary
Video

Control
Room

Slides

Workstation
Computer

PGM
VOL

UP

DN

SYSTEM POWER

ON



OFF

Welcome



LIGHTS

ALL
ON




SCREEN





Press the **VHS/VCR** button

VCR Screen

 **LIGHTS**

ALL ON





VCR Video

Transport Controls

Play

Rewind

Fast Forward

Stop

Search Rev

Search Fwd

Pause

VIDEO MUTE



ON

OFF

1:00

11/11


PGM VOL




Quit to Main Menu


Press the **VHS/VCR** button


To Exit the VCR Screen


 **LIGHTS**


ALL ON





 **SCREEN**





VCR Video

Transport Controls

Play

Rewind

Fast Forward

Stop

Search Rev

Search Fwd

Pause

VIDEO MUTE


ON


OFF

1:00

11/11

PGM VOL

 **UP**

 **DN**

Quit to Main Menu

Press the **Quit to Main Menu** button

To Use the DVD Player

MAIN MENU

PLEASE SELECT THE DEVISE YOU WISH TO USE...

VHS
VCR

DVD

Visualizer

Laptop
Computer

Auxiliary
Video

Control
Room

Slides

Workstation
Computer

SYSTEM POWER

ON

OFF

1:00

11/11

PGM
VOL

UP


DN

Welcome



LIGHTS

ALL
ON



SCREEN

UP

DN

Press the **DVD** button

DVD Screen

DVD Video

Transport Controls

Skip
Reverse

Play

Skip
Forward

Search
Rev

Stop

Search
Fwd

Pause

Menu

VIDEO MUTE

ON

OFF

1:00

11/11

PGM
VOL

UP



DN

Quit to
Main Menu



LIGHTS

ALL
ON



SCREEN



To Exit the DVD Screen

DVD Video

Transport Controls

Play

Rewind

Fast Forward

Stop

Search Rev

Search Fwd

Pause

VIDEO MUTE

ON


OFF

1:00

11/11

PGM VOL

UP





DN

Quit to Main Menu



LIGHTS

ALL ON



SCREEN

UP

DN

Press the **Quit to Main Menu** button

To Use the Aux Player

MAIN MENU

PLEASE SELECT THE DEVISE YOU WISH TO USE...

VHS
VCR

DVD

Visualizer

Laptop
Computer

**Auxiliary
Video**

Control
Room

Slides

Workstation
Computer

SYSTEM POWER

ON

OFF

1:00

11/11

PGM
VOL

UP



DN

Welcome





LIGHTS

ALL
ON




SCREEN





Press the **Aux** button


Aux Screen


 **LIGHTS**


ALL ON





 **SCREEN**





Aux Video

Transport Controls

Skip Reverse	Play	Skip Forward
Search Rev	Stop	Search Fwd
	Pause	Menu


VIDEO MUTE


ON **OFF**

1:00

11/11


PGM VOL

 **UP**


 **DN**


Quit to Main Menu


To Exit the Aux Screen


 **LIGHTS**


ALL ON





 **SCREEN**





Aux Video

Transport Controls

Play

Rewind

Fast Forward

Search Rev

Search Fwd

Stop

Pause

VIDEO MUTE


ON


OFF

1:00

11/11

PGM VOL

 **UP**

 **DN**

Quit to Main Menu

Press the **Quit to Main Menu** button

Visualizer

The Visualizer Projects Three Dimensional Objects

To Use the Visualizer

MAIN MENU

1:00

11/11



PLEASE SELECT THE DEVISE YOU WISH TO USE...




LIGHTS

ALL

ON



SCREEN



VHS
VCR

DVD

Visualizer

Laptop
Computer


Auxiliary
Video

Control
Room

Slides

Workstation
Computer

PGM
VOL



SYSTEM POWER


ON

OFF


Welcome


Press the **Visualizer** button


Visualizer Screen


 **LIGHTS**


ALL
ON





 **SCREEN**





Visualizer

Device Activated


VIDEO MUTE


ON OFF

1:00

11/11


**PGM
VOL**

 UP


 DN


Quit to
Main Menu


To Exit the Visualizer Screen


 **LIGHTS**


ALL
ON





 **SCREEN**





Visualizer

Device Activated


VIDEO MUTE


ON OFF

1:00

11/11

PGM
VOL





Quit to
Main Menu

Press the **Quit to Main Menu** button

To Use the Control Room

MAIN MENU

1:00

11/11

PLEASE SELECT THE DEVISE YOU WISH TO USE...

LIGHTS

ALL

ON

VHS
VCR

DVD

Visualizer

Laptop
Computer

Auxiliary
Video

**Control
Room**

Slides

Workstation
Computer

PGM
VOL

UP

DN

SCREEN

UP

DN

SYSTEM POWER

ON

OFF

Welcome

Press the **Control Room** button

Control Room Screen

Control Room Feed

1:00

11/11

PGM

VOL

UP

DN

Quit to
Main Menu



LIGHTS

ALL

ON



SCREEN

UP

DN


Device Activated

VIDEO MUTE


ON


OFF


To Exit the Control Room Screen


 **LIGHTS**


ALL
ON





 **SCREEN**





Control Room Feed

Device Activated


VIDEO MUTE


ON OFF

1:00

11/11

PGM
VOL

 UP

 DN

Quit to
Main Menu

Press the **Quit to Main Menu** button

To Use Slides

MAIN MENU

1:00

11/11

PLEASE SELECT THE DEVISE YOU WISH TO USE...

VHS
VCR

DVD

Visualizer

Laptop
Computer

Auxiliary
Video

Control
Room

Slides

Workstation
Computer

SYSTEM POWER

ON

OFF

PGM
VOL

UP


DN

Welcome





LIGHTS

ALL
ON



SCREEN



Press the **Slides** button

Slides Screen

1:00

11/11

PGM

VOL


UP

DN

Quit to
Main Menu

Control Room Feed

Left
Projector



Fwd

Focus

Near

Far

Power
On

Power
Off

Right
Projector



Fwd

Focus

Near

Far

Power
On

Power
Off

VIDEO MUTE

ON

OFF

LIGHTS

ALL

ON

SCREEN

UP

DN



To Exit Slides Screen

Control Room Feed

1:00

11/11

PGM

VOL

UP

DN



Quit to
Main Menu



LIGHTS

ALL

ON




SCREEN

UP

DN

Left
Projector



Fwd

Focus


Near

Far

Power
On

Power
Off

Right
Projector



Fwd

Focus

Near

Far

Power
On

Power
Off

VIDEO MUTE

ON

OFF

To Use the WorkStation Computer

MAIN MENU

PLEASE SELECT THE DEVISE YOU WISH TO USE...

VHS
VCR

DVD

Visualizer

Laptop
Computer

Auxiliary
Video

Control
Room

Slides

Workstation
Computer

SYSTEM POWER

ON

OFF

1:00

11/11

PGM
VOL

UP



DN

Welcome



LIGHTS

ALL
ON



SCREEN

UP

DN

Press the **Workstation Computer** button

Workstation Computer Screen

Workstation Computer

1:00

11/11

PGM

VOL

UP

DN

Device Activated

VIDEO MUTE

ON

OFF



Quit to
Main Menu




LIGHTS

ALL

ON



SCREEN




To Exit the Workstation Computer Screen

Workstation Computer

1:00

11/11

PGM
VOL



Device Activated

VIDEO MUTE

ON



OFF

Quit to
Main Menu



LIGHTS

ALL
ON



SCREEN



Press the **Quit to Main Menu** button

Turning off the System

MAIN MENU

1:00

11/11

PLEASE SELECT THE DEVISE YOU WISH TO USE...

VHS
VCR

DVD

Visualizer

Laptop
Computer

Auxiliary
Video

Control
Room

Slides

Workstation
Computer

PGM
VOL

UP

DN

SYSTEM POWER

ON

OFF



Welcome




LIGHTS

ALL

ON



SCREEN



On the Main Menu, Press the **Off** button